





Heavy-Duty Premium New Top Mounting Desk Mount - Single



AVLT-DM45-1 (Black)
AVLT-DM89-1 (White)




Tension Adjustment
Video Instruction


AP4-0139F

If you have any questions or concerns about this product.

1 Parts List




2a Clamp Installation




2b Grommet Installation

Clamp may also be fitted into the grommet hole featured on some desks.




Please feel free to email us at support@avlab.com.tw


3 Arm Installation



4 VESA Plate Installation




5 Monitor Installation




6 Adjust Arm Tension

a. To avoid any damage and facilitate easy adjustment, hold the Upper Arm in a horizontal position during tension adjustment.

By using the Allen Wrench you can adjust the gas spring tension in the Upper Arm. Adjust the screw **counter-clockwise (+)** to increase gas spring tension. Adjust the screw **clockwise (-)** to decrease gas spring tension.



b. If the Upper Arm rises, adjust gas spring tension screw **clockwise (-)** until it stays in a horizontal position.



c. If the Upper Arm droops, adjust gas spring tension screw **counter-clockwise (+)** until it stays in a horizontal position.

